

**ottobock.**

# Komfortpolster für Armschale

## Arm cuff comfort pads

Produktinformation  
Product Information



Quality for life



**Grüner** Punkt = rechts

**Gelber** Punkt = links


**Green** dot = right arm cuff

**Yellow** dot = left arm cuff




Klappplasphe zeigt zur  
Armbeuge

Foldable flap is showing  
towards elbow




Polster an der Armschalen-  
innenseite anheben und  
Komfortpolster an Schale  
kletten

Lift arm pad on the inner side  
of arm cuff and place comfort  
pad underneath on hook &  
loop area



Einklettposition kann an  
Armumfang angepasst  
werden

Position of comfort pad can  
be adjusted and fitted to  
individual arm size






Ottobock SE & Co. KGaA  
Max-Näder-Str. 15 · 37115 Duderstadt

Ottobock Industrials  
industrials@ottobock.com  
T +49 5527 848-1482



[www.paexo.com](http://www.paexo.com)

**Folge uns auf:**  
**Follow us on:**

-  [facebook.com/paexo](https://facebook.com/paexo)
-  [twitter.com/ottobock\\_paexo](https://twitter.com/ottobock_paexo)
-  [linkedin.com/showcase/ottobock-industrials](https://linkedin.com/showcase/ottobock-industrials)